

Standard SMW7S System: 3-Camera Trailer Installation

Required Components for 3-Camera Installation:

- 1) *20 m./ 65' F-F camera cable used in trailer
- 1) *C300P Camera
- 1) *ADD300Z Camera Cover
- 1) **CBS202 Socket
- 2) C115 Side Cameras
- 2) CB005 5m 15' M/FM camera cables
- * included in SMW7S
- ** included in CBK202

