



## **BX65KIT** For Standard Box Trucks – Straight Trucks

### Part# **BX65KIT** Installation Kit for Box/Straight Trucks

All too often after-market systems are installed without the items on hand to do an OEM level install. More time and expense can be spent hunting down the correct stainless steel screws, different size wire loom, straps, grommets, etc. This kit is designed to provide all that is needed for a faster install that is done properly. It accounts for details like the loom and wire for the reverse wire trigger. It also provides an Add-A-Circuit fuse connector to save time and not void OEM warranties by tying into random wires.

(3) 1.0 x .25 x .25 Black Rubber Grommet: for where monitor cable comes through dash



(20) 6" Black Cable Ties: For securing camera cable in trailer and binding any excess cable



(8) #3 10-16 Stainless Steel Pan-head Self-Drilling Screws  
for mounting camera, monitor, and coil cable connectors.



65' 7/16" dia. Black Wire Loom: for trailer camera cable run.



(1) Add-A Circuit Fuse Connector



(1) 3 Amp Fuse for Add-A-Circuit Fuse Connector



(1) Posi-Tap® 14-16 ga Tap (for connecting the rear trigger wire to the back-up light)



(1) Posi-Lock® 14-16 ga. Butt Splice (for connecting the Add-A-Circuit fuse connector to power supply)



10' Red 16 Gauge TEW Stranded Wire: Power wire extension

10' Black 16 Gauge TEW Stranded Wire: Ground wire extension

25' Brown 16 Gauge TEW Stranded Wire: Reverse trigger wire connection



**BX65KIT** provides the materials necessary to make your installation compliant with SAE J1292, 49CFR 393.28 and DOT regulations.

574-807-6002

[www.verityrvs.com](http://www.verityrvs.com)

Serving OEMs & Fleets

56600 Twin Branch Dr., Mishawaka, IN 46545

Woman-Owned

A division of Component Solution Services, LLC.

Est. 2002

Subject to change without notice